

TIPS FOR APPLYING PLASTERS

- Rinse the wound with (tap) water. If there is no clean water available, use a skin antiseptic.
- Do not touch the wound pad.
- Cut the bandage to size and shape.
- Never wrap a bandage around the finger in a circular pattern to avoid constriction.
- If necessary, cover the open edges of a bandage with adhesive tape (do not apply the adhesive tape in a circular manner either).
- Never leave the bandage on for longer than a day. Replace the bandage if it is dirty.
- It can be easily removed with water, baby oil, or salad oil. Any remaining adhesive residue can be removed with alcohol or mineral spirits.
- All methods for applying bandages to the hand and fingers can be applied in the same way to the foot and toes.

